

Edisecure XID 8300 - Cleaning instructions

Your Edisecure XID printer will give you years of valuable service, but does require a regular clean.

You will need to clean the rollers at least every time you replace the roll of film. This will ensure that the printer continues to operate at peak performance.

Remember too, that you should never use dirty or scratched cards, and never use a roll of dye film that may have dropped on the floor and picked up dirt particles.

Follow the instructions in this video to give your XID the clean it deserves!

Article ID: 56

Last updated: 14 Aug, 2015

Revision: 5

Maintenance & Cleaning Instructions -> Edisecure (Matica) XID -> Edisecure XID 8300 - Cleaning instructions

<https://www.visionidz.com.au/kb/entry/56/>